


PARTS LIST

Series 500 Bending Roll

Assembly, General




NOTE: When Ordering Repair Parts Always Give Model & Serial Number Of Machine, Assembly & Part Number Of Parts Required.

THE WEBB CORP.
WEBB CITY, MO.
U. S. A.

Assembly, General

Machine Serial No.


Machine: Series 900 Bending Roll
Assembly: General
PARTS DWG: BR500-100




Assembly, Main Frame

Machine Serial No.


Machine: Series 900 Bending Roll
Assembly: Main Frame
PARTS DWG: BR500-101




Assembly, Rolls Top & Front




Assembly, Rear Roll - Hand Adjust




Assembly, Rear Roll - Power Adjust




Assembly, Power Adjust




Assembly, Drive System - Power Adjust




Assembly, Tail Hinge




Assembly, 3 Roll Drive



Assembly, Drive System




Machine Serial No.:



Machine: Series 500 Bonding Roll
Assembly: Pneumatic System - Optional

110


Machine Serial No.



PARTS DWG: 3R500-11.1

Machine: Series 500 Bending Roll
Accessories: Cone Rolling Attachment (Opt)

Assembly, Power Adjust Gear Box



Assembly, Main Drive Gear Box

