

- B-46 Slide Block Guide (2)
- 101164 Slide Block
- B-10 Adjusting Block
- 101197 Nut
- 101516 Block
- 100025-6 Washer
- 100001-11 Screw
- 101448 Tension Gauge Nut Assembly
- 101198 Tension Spring
- 101162 Take-Up Support
- 101170 Take-Up Screw Assembly

- B-3 Vise Jaw
- B-14W Bed
- B-78 Vise Ratchet
- B-40 Guide Spool
- M-41 Spacer

- B-438 Apron

DO NOT SCALE DRWG.
TOLERANCE
DECIMAL DIM. ± .005
FRACTIONAL DIM. ± 1/64

- M-105 Lever
- B-106 Arm
- M-107 Collar (2)
- B-15A Leg

- B-26 Frame Rest
- M-29 Trigger
- 101529 Switch Rod
- 101530 Switch Rod Post
- M-34 Switch Trigger Axle
- M-250 Splash Guard
- B-11 Tip-Off Block
- 101538 Chip Pan

- 101453 Guide Bracket
- 100042-7 Thumb Screw
- 100004-18 Cap Screw
- 100029-2 Flat Washer

- M-92 Roller Adjuster
- 100034-5 Set Screw (2)
- 100034-6 Set Screw (2)

- 101519 Roller Support & Adjuster Assembly

- 101180 Roller Support
- 101179 Roller Axle
- 101178 Roller Axle
- 101177 Ecc. Roller Axle
- 101186 Washer (3)
- 101300 Hex Nut
- 100406-2 Ball Bearing
- 100411-2 Ball Bearing (2)

- M-156 Cap Screw
- 100029-2 Flat Washer

- M-13 Gear Case
- 100068-1 Snap Ring
- 100405-1 Ball Bearing
- M-112 Drive Shaft
- 101286 Driven Gear Ass'y.
- 100404-1 Ball Bearing (2)
- M-68 Drive Pinion
- 100056-1 Key
- 101592 Pulley Shaft
- 100053-3 Roll Pin
- 100403-2 Ball Bearing
- 101291 Gear Case Cover
- 100072-1 Expansion Plug

- 101511 Gear Box Assembly

- 101517 Belt Guard
- 100066-5 "V" Belt

- 101172-2 Pulley
- 100056-14 Key

- B-114 Wheel Plate
- 101568 Spring
- 100020-5 Nut (2)
- 101455 Pivot Bar
- M-456 Clamp (3)
- 100220-9 Hose

- 101468 Rotary Brush Assembly Complete
- 101484 Bracket Assembly
- 100412 Flange Bearing
- 101489 Flexible Casing Assembly
- 101488 Flexible Shaft Assembly
- 101473 Blade Brush Axle
- 101478 Wire Brush
- 101479 Blade Brush Guard
- 100218-1 Tubing Clamp
- 101537 Hex Nut


- B-82 Stop Bar Bracket
- B-460 Stock Stop Bar

- B-344 Stock Stop Ass'y.
- M-451 Arm - Fixed
- M-452 Arm - Hinged

WELLS MFG. CORP.		REPAIR PARTS CHART - MODEL 800	
NAME	DATE	SCALE	NO. PARTS
DATE	BY	BY	BY
10/5/54	FH		
10/5/54			
DRAWING NO. 101536			

CHANGES	
NO.	DATE

Serial Number of Saw MUST be given when ordering Repair Parts



DO NOT SCALE DRAWG.
 TOLERANCE
 DECIMAL DIM. ± .005
 FRACTIONAL DIM. ± 1/64

NAME		SCALE		NO. REV. D.	
WELLS MFG. CORP.		THREE RIVERS, MICH.		DATE	
REPAIR PARTS (HART) - MODEL 800		DATE		DRAWING NO.	
MATERIAL		CHK'D BY		101536	
DGN. BY		DATE		NO. REV. D.	
EH		6-29-54		101536	
DATE		6-29-54		DRAWING NO.	
6-29-54		101536		NO. REV. D.	

- 101523 Inside Tube Ass'y.
- 101524 Outside Tube Ass'y.
- 101526 Piston Rod Ass'y.
- M-166 Cup Leather
- 100070 Cup Washer
- M-148 Spring
- M-301 Dash Pot Assembly Complete

CHANGES	
DATE	BY
	A
	B
	C
	D

100589-1 Cord - 1 Phase
 100590-1 Cord - 3 Phase
 101419 Switch - 1 Phase
 101420 Switch - 3 Phase
 1/2 H.P. Motor

Give complete Electrical Specifications when ordering these parts

Serial Number of Saw MUST be given when ordering Repair Parts